

	Page	
<b>CHAPTER</b>	1. INTRODUCTION.....	1-1
Section	I. General Information .....	1-1
	II. Equipment Description .....	1-3
<b>CHAPTER</b>	2. OPERATING INSTRUCTIONS	
Section	I. Description and Use of Operator's Controls and Indicators .....	2-1
	II. Preventive Maintenance Checks and Services .....	2-60
	III. Operation Under Usual Conditions .....	2-105
	IV. Operation Under Unusual Conditions .....	2-137
	V. Cargo/Troop Carrier and S250 Shelter Carrier Operation .....	2-166
	VI. TOW/Armament Carrier Operation .....	2-184
	VII. Ambulance Operation .....	2-191
<b>CHAPTER</b>	3. MAINTENANCE INSTRUCTIONS .....	3-1
Section	I. Lubrication .....	3-1
	II. Troubleshooting .....	3-2
	III. Maintenance Procedures .....	3-10
<b>APPENDIX</b>	A. REFERENCES .....	A-1
<b>APPENDIX</b>	B. COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS .....	B-1
Section	I. Introduction .....	B-1
	II. Components of End Item .....	B-2
	III. Basic Issue Items .....	B-3
<b>APPENDIX</b>	C. ADDITIONAL AUTHORIZATION LIST .....	C-1
Section	I. Introduction .....	C-1
	II. Additional Authorization List .....	C-2
<b>APPENDIX</b>	D. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST .....	D-1
Section	I. Introduction .....	D-1
	II. Expendable/Durable Supplies and Materials List .....	D-2
<b>APPENDIX</b>	E. STOWAGE AND SIGN GUIDE .....	E-1
<b>APPENDIX</b>	F. ON-VEHICLE EQUIPMENT LOADING PLANS .....	F-1
<b>APPENDIX</b>	G. LUBRICATION INSTRUCTIONS .....	G-1
<b>INDEX</b>	.....	Index 1